

## RV BUG SCREEN (A10-1302VP)

PARE-INSECTES POUR VR

### For Outside Furnace Vent (Hydro Flame® 8500 Series)

Pour les événements d'appareils de chauffage extérieurs (Hydro Flame® série 8500)

- Using a flathead screwdriver, loosen the two screws on the access door (figure 1).
- Open access door and place the screen in the open area of the door so that the screen dome faces outward (figure 2).
- Close the access door and tighten the screws. The side view of the screen should appear as shown in figure 3.

Cleaning the screens is necessary for proper air flow. Inspect screens frequently and clean as needed. À l'aide d'un tournevis à tête plate, desserrer les deux vis de la porte d'accès (figure 1).

- Ouvrir la porte d'accès et placer la grille dans la zone ouverte de la porte de sorte que la coupole de la grille soit orientée vers l'extérieur (figure 2).
- Fermer la porte d'accès, puis serrer les vis. La vue latérale de la grille devrait ressembler à celle illustrée à la figure 3.

Le nettoyage des grilles est nécessaire pour assurer un flux d'air approprié. Inspecter les grilles fréquemment et nettoyer au besoin.

